



### Beneteau rudder spare parts compatibility guide

Boat Model
First 31.7
First 32
First 32
First 34.7
First 35
First 36.7 prima del 1-3-2002
First 36.7 prima del 1-3-2002
First 36.7 dopo il 1-3-2002
First 40
First 40.7 prima del 1-3-2002
First 40.7 prima del 1-3-2002
First 40.7 dopo il 1-3-2002
First 44.7
First 45
First 47.7 prima del 12-2001
First 47.7 dal 03-2002
First 47.7 2002
First 50
Figaro II

Bearing house SKU	Bottom bearing ball with rollers SKU	Top bearing ball SKU
		LS2201649B
LS2032	BWR-100-129	LS2201649B
LS2032	BWR-100-129	
LS2032	BWR-100-129	LS2201648B
M74-260P	BWR-120.5-149	BWR-085-112
M74-257	BWR-110-130	LS2201648B
	BWR-120.5-140	LS2201648B
M74-260P	BWR-120.5-149	BWR-085-112
M74-266	BWR-130-160	BWR-100-140
M74-257	BWR-110-130	LS2201648B
	BWR-120.5-140	LS2201648B
M74-260	BWR-120.5-149	BWR-085-112
	BWR-160-208	BWR-115-154
	BWR-160-208	BWR-115-154
	BWR-149-170	LS2201642B
	BWR-157-190	LS2201642B
M74-290	BWR-160-208	BWR-115-154
M74-290	BWR-160-208	BWR-115-154
	BWR-044-070	